

BLUE RED MAGENTA GREEN CYAN YELLOW WHITE BLACK VERSION TR-DOS 48 TR-DOx 48 TR-DOx 128 LOAD"" 128 LOAD"" 48

	TEST RTC	MOUSE TEST	Tiny Term	ScanCode TEST	ZX-Keys ON	RESET	NMI	WAIT	GRAPH ScrLk	<> NumLk	ZX Keyboard			
EDIT	CAPS LOCK	TRUE VIDEO	INV. VIDEO	←	↓	↑	→	GRAPHICS	DELETE	SIN	CDS	TAN	INT	RND
1 !	2 @	3 #	4 \$	5 %	6 &	7 ,	8 (9)	0 _	Q PLOT	W DRAW	E REM	R RUN	T RAND
STR \$	CHR \$	CODE	PEEK	TAB	READ	RESTORE	DATA	SGN	ABS	SQR	VAL	LEN	USR	*
Y AND RETURN	U OR IF	I AT INPUT	O POKE	P PRINT	A STOP NEW	S NOT SAVE	D STEP DIM	F TO FOR	G THEN GOTO	H GOSUB	J LOAD	K LIST	L LET	
LN	EXP	L PRINT	L LIST	BIN	IN KEY	PI								
Z COPY BEEP	X CLEAR INK	C COUNT PAPER	V CLS FLASH	B BORDER BRIGHT	N NEXT OTHER	M PAUSE INVERSE	:	;	,	/	"	+	-	
EDIT	SYMBOL SHIFT		SYMBOL SHIFT		CAPS SHIFT		CAPS SHIFT		GRAPH	£	TRUE VIDEO	INV. VIDEO	CARD	

EDIT	CAPS LOCK	TRUE VIDEO	INV. VIDEO	←	↓	↑	→	GRAPHICS	DELETE	SIN	CDS	TAN	INT	RND
1 !	2 @	3 #	4 \$	5 %	6 &	7 ,	8 (9)	0 _	Q PLOT	W DRAW	E REM	R RUN	T RAND
STR \$	CHR \$	CODE	PEEK	TAB	READ	RESTORE	DATA	SGN	ABS	SQR	VAL	LEN	USR	LN
Y AND RETURN	U OR IF	I AT INPUT	O POKE	P PRINT	A STOP NEW	S NOT SAVE	D STEP DIM	F TO FOR	G THEN GOTO	H GOSUB	J LOAD	K LIST	L LET	Z COPY BEEP
EXP	L PRINT	L LIST	BIN	IN KEY	PI	←	→	↑	↓	:	.	,	"	BREAK
X CLEAR INK	C COUNT PAPER	V CLS FLASH	B BORDER BRIGHT	N NEXT OTHER	M PAUSE INVERSE	EXTEND MODE		SYMBOL SHIFT		SYMBOL SHIFT		DELETE		
GRAPH	1	2	3	4	5	6	7	8	9	0	;	RESET	RESET	

RTC Test Test Tiny Term 1MM 1/2MM 1/2MM 1/2MM LOAD"" TR-DOS 48

RESET	TURBO	MAGIC	POWER	ROM	TAPE	TAPE IN	TAPE OUT	VIDEO	AUDIO	VGA	PRINTER	PARALLEL PORT	RGB		
KEMPSTON	SINCLAIR I	SINCLAIR II	SD-CARD	RGB	S-VIDEO	SCART	PS/2 KEYB.	WORK	PROG.	KEYBOARD					
SPEAKERS	AUDIO IN	AUDIO OUT	JOYSTICK I	JOYSTICK II	UP	DWN	SEL	↓	↑	↑	↑	SET	LOCK On/Off		
⏪	⏩	🔊	🔊	🔊	🖱️	🖱️	🖱️	🖱️	🖱️	🖱️	🖱️	🔒	🔒		
RESET	TURBO	MAGIC	POWER	ROM	TAPE	TAPE IN	TAPE OUT	VIDEO	AUDIO	VGA	PRINTER	PARALLEL PORT	RGB		
KEMPSTON	SINCLAIR I	SINCLAIR II	SD-CARD	RGB	S-VIDEO	SCART	PS/2 KEYB.	WORK	PROG.	KEYBOARD					
SPEAKERS	AUDIO IN	AUDIO OUT	JOYSTICK I	JOYSTICK II	UP	DWN	SEL	↓	↑	↑	↑	SET	LOCK On/Off		
⏪	⏩	🔊	🔊	🔊	🖱️	🖱️	🖱️	🖱️	🖱️	🖱️	🖱️	🔒	🔒		
RESET	TURBO	MAGIC	POWER	ROM	TAPE	TAPE IN	TAPE OUT	VIDEO	On/Off	ON	2M	4M	4M	2M	16M
KEMPSTON	SINCLAIR I	SINCLAIR II	SD-CARD	RGB	S-VIDEO	SCART	RGB	OFF	↑						
KEYBOARD	AUDIO IN	AUDIO OUT	JOYSTICK I	JOYSTICK II	UP	DWN	SEL	↓	↑	AUDIO					
FIRE	NMI	🖱️	🖱️	🖱️	🖱️	🖱️	🖱️	🖱️	🖱️	🖱️	🖱️	🖱️	🖱️	🖱️	🖱️

	LENINGRAD		SCORPION-256		KAY-1024		
	LENINGRAD		SCORPION-256		KAY-1024		
	sinclair		ZX-Evolution	512k	512k	16M	
	KAY-1024		Profi		Profi	1M	
	sinclair		ZX-Evolution	1M			
	Pent-EVO		Profi		KAY-1024		
	PENTAGON-1024SL		PENTAGON-128				
	PENTAGON-1024SL		PENTAGON-128				
	Profi	48k	48k	128k	128k	256k	256k
	SPECCY 2007		SPECCY 2010				
	SPECCY 2007		SPECCY 2010		Pent-EVO		

ZXM-PHOENIX

ZXM-PHOENIX